

DMX CHARTS

Channel	1 CH	2 CH	5 CH 1	5 CH 2	7 CH 1	7 CH 2	8 CH
1	DIMMER	DIMMER	DIMMER	DIMMER	RED	DIMMER	COLOR PICKER
2		DIMMER SPEED MODE	CTO	DIMMER FINE	ORANGE	RED	DIMMER
3			HUE	CTO	GREEN	ORANGE	RED
4			COLOR MACRO	COLOR MACRO	ROYAL BLUE	GREEN	ORANGE
5			DIMMER SPEED MODE	DIMMER SPEED MODE	BLUE	ROYAL BLUE	GREEN
6					LIME	BLUE	ROYAL BLUE
7					DIMMER SPEED MODE	LIME	BLUE
8							LIME
9							
10							
11							
12							
13							
14							
15							
16							
17							
18							
19							
20							
21							

Channel	9 CH	12 CH	13 CH	16 CH	19 CH	21 CH
1	DIMMER	DIMMER	RED	DIMMER	DIMMER	DIMMER
2	RED	STROBE	RED FINE	DIMMER FINE	DIMMER FINE	DIMMER FINE
3	ORANGE	RED	ORANGE	RED	RED	STROBE
4	GREEN	ORANGE	ORANGE FINE	RED FINE	RED FINE	CTO
5	ROYAL BLUE	GREEN	GREEN	ORANGE	ORANGE	HUE
6	BLUE	ROYAL BLUE	GREEN FINE	ORANGE FINE	ORANGE FINE	CROSSFADE
7	LIME	BLUE	ROYAL BLUE	GREEN	GREEN	RED
8	STROBE	LIME	ROYAL BLUE FINE	GREEN FINE	GREEN FINE	RED FINE
9	DIMMER SPEED MODE	CTO	BLUE	ROYAL BLUE	ROYAL BLUE	ORANGE
10		HUE	BLUE FINE	ROYAL BLUE FINE	ROYAL BLUE FINE	ORANGE FINE
11		COLOR MACRO	LIME	BLUE	BLUE	GREEN
12		DIMMER SPEED MODE	LIME FINE	BLUE FINE	BLUE FINE	GREEN FINE
13			DIMMER SPEED MODE	LIME	LIME	ROYAL BLUE
14				LIME FINE	LIME FINE	ROYAL BLUE FINE
15				STROBE	STROBE	BLUE
16				DIMMER SPEED MODE	CTO	BLUE FINE
17					HUE	LIME
18					COLOR MACRO	LIME FINE
19					DIMMER SPEED MODE	COLOR MACRO
20						CTO ON COLORS
21						DIMMER SPEED MODE

1 CH	2 CH	5 CH 1	5 CH 2	7 CH 1	7 CH 2	8 CH	9 CH	12 CH	13 CH	16 CH	19 CH	21 CH	Function	DMX Value	Def.
1		1	1		1	2	1	1		1	1	1	DIMMER 0~100%	000 ÷ 255	000
			2							2	2	2	DIMMER FINE 0~100%	000 ÷ 255	000
												3	STROBE Open Strobe slow to fast Open Random strobe slow to fast Open	000 ÷ 030 031 ÷ 100 101 ÷ 130 131 ÷ 200 201 ÷ 255	255
		2	3					9			16	4	CTO 2800K - 3000K 3000K - 3200K 3200K - 3400K 3400K - 3600K 3600K - 3800K 3800K - 4000K 4000K - 4200K 4200K - 4400K 4400K - 4600K 4600K - 4800K 4800K - 5000K 5000K - 5200K 5200K - 5400K 5400K - 5600K 5600K - 5800K 5800K - 6000K 6000K - 6200K 6200K - 6400K 6400K - 6600K 6600K - 6800K 6800K - 7000K 7000K - 7200K 7200K - 7400K 7400K - 7600K 7600K - 7800K 7800K - 8000K 8000K - 8200K 8200K - 8400K 8400K - 8600K 8600K - 8800K 8800K - 9000K 9000K - 9200K 9200K - 9400K 9400K - 9600K 9600K - 9800K 9800K - 10000K	000 ÷ 007 007 ÷ 014 014 ÷ 021 021 ÷ 028 028 ÷ 035 035 ÷ 042 042 ÷ 049 049 ÷ 056 056 ÷ 063 063 ÷ 070 070 ÷ 077 077 ÷ 084 084 ÷ 091 091 ÷ 098 098 ÷ 105 105 ÷ 112 112 ÷ 119 119 ÷ 126 126 ÷ 133 133 ÷ 140 140 ÷ 147 147 ÷ 154 154 ÷ 161 161 ÷ 168 168 ÷ 175 175 ÷ 182 182 ÷ 189 189 ÷ 196 196 ÷ 203 203 ÷ 210 210 ÷ 217 217 ÷ 224 224 ÷ 231 231 ÷ 238 238 ÷ 245 245 ÷ 255	000
		3						10			17	5	HUE -25 to 0 No Function 0 to +25	000 ÷ 126 127 128 ÷ 255	127
												6	CROSSFADE 0~100%	000 ÷ 255	000
				1	2	3	2	3	1	3		7	RED 0~100%	000 ÷ 255	000

1 CH	2 CH	5 CH 1	5 CH 2	7 CH 1	7 CH 2	8 CH	9 CH	12 CH	13 CH	16 CH	19 CH	21 CH	Function	DMX Value	Def.
									2	4	4	8	RED FINE 0~100%	000 ÷ 255	000
				2	3	4	3	4	3	5	5	9	ORANGE 0~100%	000 ÷ 255	000
									4	6	6	10	ORANGE FINE 0~100%	000 ÷ 255	000
				3	4	5	4	5	5	7	7	11	GREEN 0~100%	000 ÷ 255	000
									6	8	8	12	GREEN FINE 0~100%	000 ÷ 255	000
				4	5	6	5	6	7	9	9	13	ROYAL BLUE 0~100%	000 ÷ 255	000
									8	10	10	14	ROYAL BLUE FINE 0~100%	000 ÷ 255	000
				5	6	7	6	7	9	11	11	15	BLUE 0~100%	000 ÷ 255	000
									10	12	12	16	BLUE FINE 0~100%	000 ÷ 255	000
				6	7	8	7	8	11	13	13	17	LIME 0~100%	000 ÷ 255	000
									12	14	14	18	LIME FINE 0~100%	000 ÷ 255	000
		4	4					11			18	19	COLOR MACRO No Function Amber Shift on Color Macro	000+002 003+005 006+255	000
												20	CTO ON COLORS 0~100%	000 ÷ 255	000
	2	5	5	7			9	12	13	16	19	21	DIMMER SPEED MODE Preset dimmer speed from display menu Mode off Mode1 (fast speed) Mode2 (middle speed) Mode3 (slow speed)	000 ÷ 051 052 ÷ 101 102 ÷ 152 153 ÷ 203 204 ÷ 255	000
							8	2		15	15		STROBE No Function Strobe slow to fast	000 ÷ 010 011 ÷ 255	000