

DMX CHARTS

Channel	1 CH	2 CH	5 CH 1	5 CH 2	7 CH 1	7 CH 2	8 CH
1	DIMMER	DIMMER	DIMMER	DIMMER	RED	DIMMER	COLOR PICKER
2		DIMMER SPEED MODE	CTO	DIMMER FINE	ORANGE	RED	DIMMER
3			HUE	CTO	GREEN	ORANGE	RED
4			COLOR MACRO	COLOR MACRO	ROYAL BLUE	GREEN	ORANGE
5			DIMMER SPEED MODE	DIMMER SPEED MODE	BLUE	ROYAL BLUE	GREEN
6					LIME	BLUE	ROYAL BLUE
7					DIMMER SPEED MODE	LIME	BLUE
8							LIME
9							
10							
11							
12							
13							
14							
15							
16							
17							
18							
19							
20							
21							

Channel	9 CH	12 CH	13 CH	16 CH	19 CH	21 CH
1	DIMMER	DIMMER	RED	DIMMER	DIMMER	DIMMER
2	RED	STROBE	RED FINE	DIMMER FINE	DIMMER FINE	DIMMER FINE
3	ORANGE	RED	ORANGE	RED	RED	STROBE
4	GREEN	ORANGE	ORANGE FINE	RED FINE	RED FINE	CTO
5	ROYAL BLUE	GREEN	GREEN	ORANGE	ORANGE	HUE
6	BLUE	ROYAL BLUE	GREEN FINE	ORANGE FINE	ORANGE FINE	CROSSFADE
7	LIME	BLUE	ROYAL BLUE	GREEN	GREEN	RED
8	STROBE	LIME	ROYAL BLUE FINE	GREEN FINE	GREEN FINE	RED FINE
9	DIMMER SPEED MODE	CTO	BLUE	ROYAL BLUE	ROYAL BLUE	ORANGE
10		HUE	BLUE FINE	ROYAL BLUE FINE	ROYAL BLUE FINE	ORANGE FINE
11		COLOR MACRO	LIME	BLUE	BLUE	GREEN
12		DIMMER SPEED MODE	LIME FINE	BLUE FINE	BLUE FINE	GREEN FINE
13			DIMMER SPEED MODE	LIME	LIME	ROYAL BLUE
14				LIME FINE	LIME FINE	ROYAL BLUE FINE
15				STROBE	STROBE	BLUE
16				DIMMER SPEED MODE	CTO	BLUE FINE
17					HUE	LIME
18					COLOR MACRO	LIME FINE
19					DIMMER SPEED MODE	COLOR MACRO
20						CTO ON COLORS
21						DIMMER SPEED MODE

1 CH	2 CH	5 CH 1	5 CH 2	7 CH 1	7 CH 2	8 CH	9 CH	12 CH	13 CH	16 CH	19 CH	21 CH	Function	DMX Value	Def.
1		1	1		1	2	1	1		1	1	1	DIMMER 0~100%	000 ÷ 255	000
			2							2	2	2	DIMMER FINE 0~100%	000 ÷ 255	000
												3	STROBE Open Strobe slow to fast Open Random strobe slow to fast Open	000 ÷ 030 031 ÷ 100 101 ÷ 130 131 ÷ 200 201 ÷ 255	255
		2	3					9			16	4	CTO 2800K - 3000K 3000K - 3200K 3200K - 3400K 3400K - 3600K 3600K - 3800K 3800K - 4000K 4000K - 4200K 4200K - 4400K 4400K - 4600K 4600K - 4800K 4800K - 5000K 5000K - 5200K 5200K - 5400K 5400K - 5600K 5600K - 5800K 5800K - 6000K 6000K - 6200K 6200K - 6400K 6400K - 6600K 6600K - 6800K 6800K - 7000K 7000K - 7200K 7200K - 7400K 7400K - 7600K 7600K - 7800K 7800K - 8000K 8000K - 8200K 8200K - 8400K 8400K - 8600K 8600K - 8800K 8800K - 9000K 9000K - 9200K 9200K - 9400K 9400K - 9600K 9600K - 9800K 9800K - 10000K	000 ÷ 007 007 ÷ 014 014 ÷ 021 021 ÷ 028 028 ÷ 035 035 ÷ 042 042 ÷ 049 049 ÷ 056 056 ÷ 063 063 ÷ 070 070 ÷ 077 077 ÷ 084 084 ÷ 091 091 ÷ 098 098 ÷ 105 105 ÷ 112 112 ÷ 119 119 ÷ 126 126 ÷ 133 133 ÷ 140 140 ÷ 147 147 ÷ 154 154 ÷ 161 161 ÷ 168 168 ÷ 175 175 ÷ 182 182 ÷ 189 189 ÷ 196 196 ÷ 203 203 ÷ 210 210 ÷ 217 217 ÷ 224 224 ÷ 231 231 ÷ 238 238 ÷ 245 245 ÷ 255	000
		3						10			17	5	HUE -25 to 0 No Function 0 to +25	000 ÷ 126 127 128 ÷ 255	127
												6	CROSSFADE 0~100%	000 ÷ 255	000
				1	2	3	2	3	1	3		7	RED 0~100%	000 ÷ 255	000

1 CH	2 CH	5 CH 1	5 CH 2	7 CH 1	7 CH 2	8 CH	9 CH	12 CH	13 CH	16 CH	19 CH	21 CH	Function	DMX Value	Def.
									2	4	4	8	RED FINE 0~100%	000 ÷ 255	000
				2	3	4	3	4	3	5	5	9	ORANGE 0~100%	000 ÷ 255	000
									4	6	6	10	ORANGE FINE 0~100%	000 ÷ 255	000
				3	4	5	4	5	5	7	7	11	GREEN 0~100%	000 ÷ 255	000
									6	8	8	12	GREEN FINE 0~100%	000 ÷ 255	000
				4	5	6	5	6	7	9	9	13	ROYAL BLUE 0~100%	000 ÷ 255	000
									8	10	10	14	ROYAL BLUE FINE 0~100%	000 ÷ 255	000
				5	6	7	6	7	9	11	11	15	BLUE 0~100%	000 ÷ 255	000
									10	12	12	16	BLUE FINE 0~100%	000 ÷ 255	000
				6	7	8	7	8	11	13	13	17	LIME 0~100%	000 ÷ 255	000
									12	14	14	18	LIME FINE 0~100%	000 ÷ 255	000
		4	4					11			18	19	COLOR MACRO No Function Amber Shift on Color Macro	000÷002 003÷005 006÷255	000
												20	CTO ON COLORS 0~100%	000 ÷ 255	000
	2	5	5	7			9	12	13	16	19	21	DIMMER SPEED MODE Preset dimmer speed from display menu Mode off Mode1 (fast speed) Mode2 (middle speed) Mode3 (slow speed)	000 ÷ 051 052 ÷ 101 102 ÷ 152 153 ÷ 203 204 ÷ 255	000
							8	2		15	15		STROBE No Function Strobe slow to fast	000 ÷ 010 011 ÷ 255	000

1 CH	2 CH	5 CH 1	5 CH 2	7 CH 1	7 CH 2	8 CH	9 CH	12 CH	13 CH	16 CH	19 CH	21 CH	Function	DMX Value	Def.
													COLOR PICKER		
													No Function	000 ÷ 000	
													3200K	001 ÷ 003	
													71	004 ÷ 007	
													97	008 ÷ 011	
													100	012 ÷ 015	
													101	016 ÷ 019	
													102	020 ÷ 023	
													103	024 ÷ 027	
													104	028 ÷ 031	
													105	032 ÷ 035	
													106	036 ÷ 039	
													107	040 ÷ 043	
													110	044 ÷ 047	
													111	048 ÷ 051	
													113	052 ÷ 055	
													115	056 ÷ 059	
													116	060 ÷ 063	
													117	064 ÷ 067	
													118	068 ÷ 071	
													119	072 ÷ 075	
													120	076 ÷ 079	
													121	080 ÷ 083	
													122	084 ÷ 087	
													124	088 ÷ 091	
													126	092 ÷ 095	
													128	096 ÷ 099	
													130	100 ÷ 103	
													132	104 ÷ 107	
													134	108 ÷ 111	
													135	112 ÷ 115	
													136	116 ÷ 119	
						1							137	120 ÷ 123	
													138	124 ÷ 127	000
													139	128 ÷ 131	
													141	132 ÷ 135	
													144	136 ÷ 139	
													147	140 ÷ 143	
													151	144 ÷ 147	
													152	148 ÷ 151	
													156	152 ÷ 155	
													157	156 ÷ 159	
													158	160 ÷ 163	
													161	164 ÷ 167	
													164	168 ÷ 171	
													165	172 ÷ 175	
													166	176 ÷ 179	
													170	180 ÷ 183	
													174	184 ÷ 187	
													179	188 ÷ 191	
													180	192 ÷ 195	
													181	196 ÷ 199	
													182	200 ÷ 203	
													195	204 ÷ 207	
													197	208 ÷ 211	
													198	212 ÷ 215	
													200	216 ÷ 219	
													201	220 ÷ 223	
													202	224 ÷ 227	
													203	228 ÷ 231	
													204	232 ÷ 235	
													205	236 ÷ 239	
													206	240 ÷ 243	
													702	244 ÷ 247	
													730	248 ÷ 251	
													777	252 ÷ 255	